



**GREEN CHEM**  
LABORATORIES

## TECHNICAL DATA SHEET



**NAME:** BLAST OUT

**PART NUMBER(S):** E5001

### PRODUCT DESCRIPTION:

**Blast Out** delivers continuous maintenance of urinals at less cost and effort. Is specifically made to eat hardened uric salts in the pipe. It deodorizes as it is working, removes years of build-up and prevents new build-up forming. Lasts +30 days.

### Features and Benefits:

- Recyclable
- Powerful cleaner and de-scaler removes years of build-up and prevents new buildup from forming
- Prevents costly plumbing bills from blocked pipes
- Eliminates a major source of urinal odors deep in pipes and emits a light, fresh scent
- No tools, tapes, or screws required. Simple, quick installation
- No metal parts to deposit rust or scratch porcelain
- In-urinal placement discourages vandalism

**Quantities:**  
36 UNITS/CASE



[WWW.GREENCHEMLABS.COM](http://WWW.GREENCHEMLABS.COM)

**CUSTOMER SERVICE: 1-800-946-3151 | FAX: 1-800-336-9068**





**NAME:** BLAST OUT

**PART NUMBER(S):** E5001

### Initial Bracket Installation

**Step 1:** Remove the mounting bracket, refill cartridge, and fragrance cap from their packaging. For your convenience, each starter kit and replacement pack includes a pair of disposable gloves.

**Step 2:** Orient the mounting bracket with the arrowhead extensions pointing up with the logo facing you.

Position the arrowhead extensions of the mounting bracket straight up and down to line up with two water opening holes along the top inner rim of the urinal. Push the arrowheads straight into the water openings until the unit securely hangs from the holes.

**NOTE:** It is okay to bend the arrowhead extensions as necessary in order to reach the water opening holes.

**Step 3:** Assemble the refill unit by inserting the fragrance cap into the front of the refill cartridge. Holding the refill so the logo is facing out, slide the bottom of the unit into the bracket first, followed by the top, until it 'snaps' into place.

### CAUTION

**In case of eye contact:** If irritation or redness develops, move victim away from exposure and into fresh air. Flush eyes with clean water. If symptoms persist, seek medical attention.

**Skin:** First aid is not normally required. However, it is good practice to wash any chemical from the skin.

**Inhalation:** First aid is not normally required. If breathing difficulties develop, move victim away from source of exposure and into fresh air. Seek immediate medical attention.

**Ingestion:** First aid is not normally required. However, if swallowed and symptoms develop, seek medical attention. Do NOT induce vomiting.

**Skin/Hand Protection:** Not required based on the hazards of the material. However, it is considered good practice to wear the disposable provided gloves when handling the Blast Out. Refer to SDS for additional information. Keep out of reach of children.