

# TECHNICAL DATA SHEET



NAME: VANQUISH

PART NUMBER(S): AL221-4, AL221-5, AL221-30, AL221-55

## PRODUCT DESCRIPTION:

Vanquish ia a concentrated versatile cleaner and broad-spectrum disinfectant that has multiple uses on a wide variety of surfaces. It will clean, disinfect and deodorize virtually any hard, nonporous surface. It is also authorized by the USDA for use in meat and poultry plants and other foodprocessing facilities. It cleans without abrasives, and deodorizes by killing the microorganisms that cause offensive odors.

#### Features and Benefits:

- A broad-spectrum disinfectant, sanitizer, virucide and mildewstat
- Active in hard water up to 400 ppm hardness
- Effectively inhibits the growth of mold and mildew and the odors caused by them

## Use on:

- Hospitals
- Dairies, poultry and hog farms
- Prisons
- Exercise facilities
- Day cares
- Refrigeration equipment
- Restrooms
- Ultrasound transducers
- Food-processing plants
- Shoe bath sanitizer
- Air conditioners
- Ultrasonic baths

## **Effective Against:**

- Staphylococcus auresus (VISA & MRSA)
- Influenza Type A/Brazil
- Campylobacter jejuni
- Enterobacter aerogenes
- Enterococcus faecalis (VRE) HCV)
- Escherichia coli (ESBL)
- Acinetobacter baumannii
- Legionella pneumophilia
- Herpes Simplex Virus Type 2
- Salmonella enterica
- Hepatitis B & C Virus (HBV &

- Adenovirus Type 5 and 7
- Shigella dysenteriae
- Pseudomonas aeruginosa
- HIV-1
- Salmonella typhi
- Vaccina
- Trichophyton mentagrophytes
  And more

## **Properties:**

Appearance.....Colorless liquid Specific gravity......1.01 pH.....12.40

## **Quantities:**

4X1 GALLONS (AL221-4,) 5 GALLON PAIL (AL221-5) 55 GALLON DRUM (AL221-30) 30 GALLON DRUM (AL221-55) **Directions** Complete directions on product label To Clean and Disinfect: Dilute 2 ounces in one gallon of water. Contact time: 10 minutes. To Clean and Sanitize: Dilute 2 ounces in 4 gallons of water. Contact time: 60 seconds

## Authorizations

**EPA Registered Product.** 



WWW.GREENCHEMLABS.COM

CUSTOMER SERVICE: 1-800-946-3151 FAX: 1-800-336-9068



